

AddInfo ..... 1

# Device Load Check

x Device가 Load

## AddInfo

- ComiIDE LogView Device Load

**Clear** Log Level **1 : Log only when error occurred**  **Find**

Time	Channel	Code	Command	Info
23:21:32,750	netID 0	100	EtherCAT Load	Complete
23:21:32,773	netID 1	100	EtherCAT Load	Complete

- 가

From: <https://www.comizoa.com/info/> - -

Permanent link: <https://www.comizoa.com/info/doku.php?id=application:comiide:troubleshooting:deviceload&rev=1559016806>

Last update: **2024/07/08 18:23**