

.....	1
OpDrop	1
Disconnect	2
CRC Error	2


x 가




- Master가 OpState AIStatus가 SafeOP , OpDrop Count가 가 ,
- Drvier , OpStatus가 , Servo-Off ,

Disconnect

Topology View



CRC Error



• CRC 가 , ErrorCount

From:

<https://www.comizoa.com/info/> - -

Permanent link:

https://www.comizoa.com/info/doku.php?id=application:comiide:monitor:100_netstate:30_opdrop&rev=1617122799

Last update: 2024/07/08 18:23