


Table of Contents

Alarm History

× 알람 이력을 확인할 수 있습니다.



- Main - Tool EtherCAT - Alarm.H 클릭

No	Alarm Code	Sub Index	Diag Code	Raw Data
Newest				
-	80,1	0x13	80	0x50010002FF50E800
History				
0	80,4	0x6	80	0x50040002FF50E800
1	80,4	0x7	80	0x50040002FF50E800
2	80,4	0x8	80	0x50040002FF50E800
3	80,4	0x9	80	0x50040002FF50E800
4	80,4	0xA	80	0x50040002FF50E800
5	80,4	0xB	80	0x50040002FF50E800
6	80,4	0xC	80	0x50040002FF50E800
7	80,4	0xD	80	0x50040002FF50E800
8	80,0	0xE	80	0x50000002FF50E800
9	80,4	0xF	80	0x50040002FF50E800
10	80,4	0x10	80	0x50040002FF50E800
11	27,4	0x11	27	0x1B040002FF1BE800
12	27,4	0x12	27	0x1B040002FF1BE800
13	80,1	0x13	80	0x50010002FF50E800

x 드라이버의 종류에 따라 지원하지 않을 수 있습니다.

From:

<https://www.comizoa.com/info/> - -

Permanent link:

<https://www.comizoa.com/info/doku.php?id=application:comiide:monitor:ahistory&rev=1617116614>

Last update: **2024/07/08 18:23**