

Intro ..... 1  
Logging ..... 1  
Interval ..... 3  
LogType ..... 4


# LogMode

× API

LogMode

## Intro

- LogMoed API Stop API , 1)
- 'Log' LogMode
- /



## Logging

- API
- ',' API
- out type parameter "null" , logging
- parameter "Invalid parameter" , logging  
"Logging Start"

```

Shell
LOG> ecmSxSt_GetPosition(0,0,1,null);ecmSxSt_GetCurTorque(0,0)
      Invalid parameter
LOG> ecmSxSt_GetPosition(0,0,1,null);ecmSxSt_GetCurTorque(0,0, null)
      Logging Start

LOG> stop
      Logging Stopped

LOG> open
LOG> save
      Command Saved

LOG> load
LOG> ecmSxSt_GetPosition(0,0,1,null);ecmSxSt_GetCurTorque(0,0, null)


```

```

LOG> stop
LOG> open
LOG> save
LOG> load

```

- stop : logging "Logging Stopped"
- open : logFile
- save :
- load :
- exit : LogMode NormalMode



### Interval

- Logging

```

Shell
> log

LOG> interval
    Interval = 10 ms

LOG> interval(1)
    Log Interval (ms) : 10 → 1

LOG> microsec
    Resolution Changed : MiliSecond → MicroSecond

LOG> interval
    Interval = 1000 us

LOG> interval(500)
    Log Interval (us) : 1000 → 500

LOG> milisec
    Resolution Changed : MicroSecond → MiliSecond

LOG> interval
    Interval = 1 ms

LOG>

```

```

LOG> interval
LOG> interval(1)
LOG> microsec
LOG> interval
LOG> interval(500)
LOG> milisec


```

- interval : log 10ms
- interval(1) : log 1ms
- microsec : log us
- interval : microsec milisec
- interval(500) : microsec microsec 가

x logging pc  
 , microsec pc

### LogType

- Memory Queue




### Memory

- MemSize Memory

- , Stop

### Queue

- QueueSize , stop



- toqueue : Queue
- quesize : queueSize line
- quesize(20000) : quesize 20000
- tomem : Memory Shell
- memsize : MemorySize line

- memsize(20000) : MemorySize 20000 .
- dirsize : log file . dirSize  
가 , 가 file .
- dirsize(2048) : dirSize 2048 . MB .

1)

Return out

From:  
<https://www.comizoa.com/info/> - -

Permanent link:  
[https://www.comizoa.com/info/doku.php?id=application:comiide:tool:shell:shell\\_logmode&rev=1559007493](https://www.comizoa.com/info/doku.php?id=application:comiide:tool:shell:shell_logmode&rev=1559007493)

Last update: **2024/07/08 18:23**