

Table of Contents

Timer Resolution 확인	1
Timer Resolution 설정	1

Winodws Timer Resolution

× Winodws Timer의 Resolution을 확인하거나 변경하는 방법에 대한 안내 페이지입니다.

Timer Resolution 확인

- Shell 실행 (**Shell 실행** 참조)
- TimerResolution 입력

```
Shell
> TimerResolution
Current : 1(ms)
Max : 15.6001(ms)
Min : 0.5(ms)
> |
```

Timer Resolution 설정

- TimerResolution(설정값) 입력

```
TimerResolution(0.5)
```

```
Shell
> TimerResolution
Current : 1(ms)
Max : 15.6001(ms)
Min : 0.5(ms)

> TimerResolution(0.5)
TimerResolution : 1 → 0.5

> TimerResolution
Current : 0.5(ms)
Max : 15.6001(ms)
Min : 0.5(ms)
> |
```

- TimerResolution 확인

From:

<https://www.comizoa.com/info/> - -

Permanent link:

https://www.comizoa.com/info/doku.php?id=application:comiide:tool:shell:shell_timer_resolution&rev=1575618560

Last update: **2024/07/08 18:23**