

NEMO Master Board 1

NEMO Master Board 1

..... 2

..... 3

NEMO


× NEMO

NEMO Master Board


NEMO Master Board

(NemoFWU.exe)


- 1. - Firmware - NemoFWU.exe
- 2. RT(LX520), ML2(LX530S), ML3(LX530), SS3(LX540/H)




- 가 DLL
- Firmware DLL




- Browse .dat





- Start



From:
<https://www.comizoa.com/info/> - -

Permanent link:
https://www.comizoa.com/info/doku.php?id=faq:comiapp:fwupdater:01_nemo&rev=1625622850

Last update: **2024/07/08 18:22**