

**NEMO Master Board** ..... 1  
..... 2  
..... 3


# NEMO

× NEMO


## NEMO Master Board

(NemoFWU.exe)


- 1. - Firmware - NemoFWU.exe
- 2. RT(LX520), ML2(LX530S), ML3(LX530), SS3(LX540/H)




- 가 DLL  
- Firmware DLL




- Browse .dat





- Start



From:  
<https://www.comizoa.com/info/> - -

Permanent link:  
[https://www.comizoa.com/info/doku.php?id=faq:comiapp:fwupdater:01\\_nemo&rev=1626249204](https://www.comizoa.com/info/doku.php?id=faq:comiapp:fwupdater:01_nemo&rev=1626249204)

Last update: **2024/07/08 18:22**