

**C-NET Setup** ..... 1  
    Contents ..... 1  
**1. PC** ..... 1  
**2. DC 24V 가** ..... 1  
**3. C-NET Download** ..... 2  
4. .... 2  
**5. comIDE** ..... 3

# C-NET Setup

× C-NET

## C-NET Setup

### Contents


- 1. PC COMI-LX412a/b
- 2. cnD00-32 DC 24V 가
- 3. C-NET Download
- 4.
- 5. comiIDE

## 1. PC

- PC가 COMI-LX412a/b
- cnD00-32 COMI-LX412a/b RJ-45

## 2. DC 24V 가

- DC Power Supply DC 24V 가
- 24V가 (DC24V , 24V) GND가 (DC 24V , 0V)가
- 가


|  | Pin # | Description                       |
|---|-------|-----------------------------------|
|   | 1     | External power DC +24 (P24 IN)    |
|   | 2     | External power DC Ground (N24 IN) |

### 3. C-NET Download

• comizoa.info

download

C-NET



• Package

Download

#### C-Net


| Package  | Example | Manual | Certificate | ETC                                | History                         |
|----------|---------|--------|-------------|------------------------------------|---------------------------------|
| v1.1.0.0 |         |        |             | <a href="#">Download (Package)</a> | <a href="#">Download (Core)</a> |
| v1.0.0.0 |         |        |             | <a href="#">Download</a>           |                                 |

### 4.

• COMI-LX412a/b


가

### COMI-LX412a/b C-Net Digital I/O Board가




## 5. comiIDE

- comiIDE



- Scan      CNet



From:

<https://www.comizoa.com/info/> - -

Permanent link:

[https://www.comizoa.com/info/doku.php?id=faq:downloadandsetup:c-net:00\\_c-net\\_setup&rev=1625647935](https://www.comizoa.com/info/doku.php?id=faq:downloadandsetup:c-net:00_c-net_setup&rev=1625647935)

Last update: **2024/07/08 18:22**