




..... 1

..... 1

..... 1

# B

× B



1)



2)

AxisList

0\* 1 2 3

Setup

Axis 0  Multi Select

Pulse Output Mode	4 : CW & CCW 1
Encoder Input Mode	0 : 1x A/B Phase
Feedback Inverse	Disable
In/Out Ratio	1
<b>Signal 1</b>	
Alarm Logic	LogicA
Alarm Mode	Immediate_Stop
EL Logic	LogicA
Inposition Logic	LogicA
Origin Logic	LogicA
EL Stop Mode	Immediate_Stop
Inposition Enable	Disable
<b>Signal 2</b>	

**Feedback Speed Check**  
실제 모션의 속도를 확인하는 기능 사용 여부를 설정합니다.

Sx Speed

Speed Mode

Work Speed


Acceleration

Deceleration

Initial Speed

Max Speed

Min Speed



From:

<https://www.comizoa.com/info/> - -

Permanent link:

[https://www.comizoa.com/info/doku.php?id=faq:motion:common:12\\_el\\_setting&rev=1624507298](https://www.comizoa.com/info/doku.php?id=faq:motion:common:12_el_setting&rev=1624507298)

Last update: 2024/07/08 18:22