

# Table of Contents

API ..... 1

# API

---

- API Description
  - ecGn
    - ecGn\_LoadDevices
  - ecmSx
    - ecmSxCfg\_SetUnitDist
  - ecNet
    - ecNet\_GetAIState
    - ecNet\_GetCfgSlaveCount
    - ecNet\_GetVerInfo
    - ecNet\_IsBootCompt
    - ecNet\_ScanSlaves
    - ecNet\_SetAIState
- Error Code
  - ErrorCode : -21056
  - ErrorCode : -21070
  - ErrorCode : -21072
  - ErrorCode : -21086
  - ErrorCode : -5
  - ErrorCode : -8
- Example
  - Check Reverse Connection
  - CMP One
  - List Motion
  - Version Compare
- Info
  - netID

From:

<https://www.comizoa.com/info/> - -

Permanent link:

[https://www.comizoa.com/info/doku.php?id=platform:ethercat:100\\_api:start&rev=1624437201](https://www.comizoa.com/info/doku.php?id=platform:ethercat:100_api:start&rev=1624437201)

Last update: **2024/07/08 18:22**