


Configurator ..... 1  
..... 1

# Configurator


x Configurator

### Configurator

- Slave
- Slave Topology Map
- Slave Address, SyncMode
- Slave InPDO Map, OutPDO Map
- Master



ComilDE Main tab Config



From:  
<https://www.comizoa.com/info/> - -

Permanent link:  
[https://www.comizoa.com/info/doku.php?id=platform:ethercat:1\\_setup:10\\_config:10\\_configurator&rev=1544501213](https://www.comizoa.com/info/doku.php?id=platform:ethercat:1_setup:10_config:10_configurator&rev=1544501213)

Last update: 2024/07/08 18:22