


Setup 1
 Scan Checking 2
 Scan Option 2
 Error 3
 Base Address (Except for 402 profile) 3

Setup

× Configurator



• Setup

Setup

Config Setup

Scan Checking

- Vendor ID
- Product Code
- Revision Number
- Serial Number

Scan Option

- Tree 로 보기
- 읽기 실패한 모듈만 재스캔
- Read 0xF050
- Alias 가 바뀐 경우에만 EEPROM에 Download

Error

- RevisionNo 가 다를 시 에러로 처리
- Unknown Slave 에러로 처리

Base Address (Except for 402 profile)

Base Address

- For COMIZOA Slaves
- For other slaves

DC Measure

- Dc Measure on downloading

- Configuration

- IDE

- IDE Update IDE

Scan Checking

- Slave

- VendorID Product Code

- Revision Number
 - Revision Number가 , Scan 가

Scan Option

Tree

- Slave List

- Tree , Slave Type Tree

- Scan Tree가

- , Scan Scan Scan
 - , 'ReScan All' Scan

Read 0xF050

- Slot MDP Type , 가 slot
 - , SlotInfo Tab slot 가

Alias가 EEPROM Download

- Write , 가 EEPROM

Error

- 가 , Download .

Base Address (Except for 402 profile)

- 402 Profile(Driver) Base Address .
- DeviceID Switch Base Address 0~255 0~15 Address가 .

From:
<https://www.comizoa.com/info/> - -

Permanent link:
https://www.comizoa.com/info/doku.php?id=platform:ethercat:1_setup:10_config:20_desc:05_setup&rev=1587052823

Last update: **2024/07/08 18:22**