



Addressing 1
Index 1
Address 2
Custom 2
Auto 4

Addressing


x Slave Mapping




- Index : Mapping
- Address : Mapping
- Custom : User Define Mapping
- Auto : Device Type




- Index 가
- IO ,




• Custom Main IoMap



• Module Drag Map




- Drop Map Channel



- Channel Map

Auto



- Check DeviceType¹⁾
 - 1 , DeviceID Switch
- Station Alias Selection



1)

401 MocoController가 IO, 402 Driver, 5001

From:

<https://www.comizoa.com/info/> - -

Permanent link:

https://www.comizoa.com/info/doku.php?id=platform:ethercat:1_setup:10_config:20_desc:50_addressing&rev=1586760912

Last update: **2024/07/08 18:22**