

..... 1

# Address

x Address

- Slave Info - Property



- EEPROM, Download

- 가 , ( **Pr 7.41** )
- EEPROM

- IO Slave 0x200 BaseAddress
- 1 , Configurator 0x201
- 

From:  
<https://www.comizoa.com/info/> - -

Permanent link:  
[https://www.comizoa.com/info/doku.php?id=platform:ethercat:1\\_setup:10\\_config:20\\_details:20\\_physaddr&rev=1560401878](https://www.comizoa.com/info/doku.php?id=platform:ethercat:1_setup:10_config:20_details:20_physaddr&rev=1560401878)

Last update: **2024/07/08 18:22**