

NEMO Master Board 1
NEMO Master Board 1
..... 2
..... 3

NEMO


× NEMO

NEMO Master Board


NEMO Master Board

(NemoFWU.exe)


- 1. - Firmware - NemoFWU.exe
- 2. RT(LX520), ML2(LX530S), ML3(LX530), SS3(LX540/H)




- 가 DLL
- Firmware DLL




- Browse .dat





- Start



From: <https://www.comizoa.com/info/> - -

Permanent link: https://www.comizoa.com/info/doku.php?id=practice:nemo_%ED%8E%8C%EC%9B%A8%EC%96%B4_%EC%97%85%EB%8D%B0%EC%9D%B4%ED%8A%B8&rev=1625630726

Last update: 2024/07/08 18:23