



# summary

---

```
namespace ...
{
    public class ...
    {
        public void Init()
        {
            // Master Device
            InitMasterDevice();

            // Config Scan . ( )
            CheckChannel();

            // 가
            AxisServoOn();

            //
            AxisHomeReturn();
        }

        private void InitMasterDevice()
        {
            //
            DeviceLoad();

            // 가
            CompareSlaveCount();
            // SW Version(FW, WDM, SDK)
            GetVersionCompResult();
            // Input / Output
            CheckReveseConnection();
            // Network alStatus OP
            SetAlStateToOP();
        }

        private bool DeviceLoad() {}
        private bool CompareSlaveCount() {}
        private bool GetVersionCompResult() {}
        private bool CheckReveseConnection() {}
        private bool SetAlStateToOP() {}
        private bool CheckChannel() {}
        private bool AxisServoOn() {}
        private bool AxisHomeReturn() {}
    }
}
```

From:  
<https://www.comizoa.com/info/> - -

Permanent link:  
[https://www.comizoa.com/info/doku.php?id=platform:ethercat:70\\_users\\_guide:00\\_cookbook:20\\_systeminit:10\\_summary&rev=1620968402](https://www.comizoa.com/info/doku.php?id=platform:ethercat:70_users_guide:00_cookbook:20_systeminit:10_summary&rev=1620968402)

Last update: **2024/07/08 18:22**