





# DLL\_Logger

× DLL\_Logger

- 


1 Comiide.exe



- 

Motion view

DLL



- Start DLL\_Logger .
- **Start** Logging .
- Memory **Dump** File Log 가 Viewer file
- LogType LogView , , **Stop** Log 가

The screenshot displays the DLL\_Logger application interface. The main window is titled 'DLL Log' and contains a list of log entries with timestamps and command details. The control panel on the right, titled 'SxMotion', includes:

- Axis:** Axis0
- Position Monitor:** Command Position (0) and Feedback Position (0) with a 'Reset Position' button.
- Jog Mode Settings:**
  - Velocity Move (Jog)
  - Relative Position Move (Distance: 10000)
  - Absolute Position Move (Position1: 0, Position2: 10000)
- Speed Settings:** Speed Ratio (%) slider set to 100, with a 'Set Speed Pattern...' button.
- Control Buttons:** Jog (-), Stop, Emg Stop, and Jog (+).

### DLL\_Logger

### DLL\_Logger

From: <https://www.comizoa.com/info/> - -

Permanent link: [https://www.comizoa.com/info/doku.php?id=practice:dll\\_logger\\_%EC%82%AC%EC%9A%A9%EB%B2%95&rev=1625641528](https://www.comizoa.com/info/doku.php?id=practice:dll_logger_%EC%82%AC%EC%9A%A9%EB%B2%95&rev=1625641528)

Last update: **2024/07/08 18:23**